


# SP-S214

## Quick Reference Guide



Ver. Q3

All Rights Reserved. Copyright 2021

## Specification

### System

CPU Support	Core™ i7-7700T, Quad Core, 2.9GHz, 8M cache Core™ i5-7500T, Quad Core, 2.7GHz, 6M cache Core™ i3-7101TE, Dual Core, 3.4GHz, 3M cache Celeron® G3930TE, Dual Core, 2.7GHz, 2M cache Intel® Q170/H110
Memory Support	2 x DDR4 2133MHz SO-DIMM sockets (up to 32GB)
Storage	2 x 2.5" SATA III HDD/SSD (support RAID 0/1 in Q170 SKU only)
Power Input	AC input ATX 250W
Operating System	Windows 10 IoT Enterprise (64bit)
Dimensions (W x H x D)	585 x 377 x 107.15mm
System Weight	11.8kg
Mounting Support	Wall mount / VESA75,100 / Panel mount
Certifications	FCC / CE

### I/O Ports

Display	2 x DVI-D
USB	4 x USB 3.0 / 4 x USB 2.0
Audio	1 x Line In / 1 x Line Out / 1 x Mic In
LAN	2 x RJ45 ports LAN1: Intel® PHYI 219LM (10/100/1000 Mbps) LAN2: Intel® LAN 210AT (10/100/1000 Mbps) Support Wake-on-Lan, PXE
Serial Ports	4 COM ports / COM1 for RS-232/422/485 COM2/COM3/COM4 for RS-232 COM1/COM2/COM4 support +5V / +12V / RI selectable
Expansion Slots	1 x PCIe (x16) / 1x half-sized Mini PCIe
Power On/Off	1 x power button switch 1 x 2-pin connector for remote power button
Parallel Port	1 x Parallel Port (SPP/EPP/ECP)
Antenna Hole	2 x antenna holes

### Display


LCD	21.5" TFT LCD(LED) resolution FHD (16:9) 1920x1080
Touchscreen	21.5" P-CAP touch panel

### Environment

Operating Temp.	HDD: 0°C~45°C (32°F~113°F) / SSD: 0°C~50°C (32°F~122°F)
Storage Temp.	-20°C~80°C(-4°F~176°F)
Humidity	20%~90% (no condensation)

## Jumper Setting


**CAUTION!** Danger of explosion may occur if the battery is replaced incorrectly. Replace batteries only with the same or equivalent type recommended by the manufacturer. Dispose the used batteries according to the manufacturer's instructions.




# System Overview

(Unit: mm)


## Front View




## Rear View




## Rear I/O View




## Left Side View




## Right Side View




## Top View



## Bottom View




## Wall Mount Cut-out Dimensions



# Quick Setup


## Installing VESA Mount (optional)



### VESA Mount Accessories (optional)

- |                              |   |
|------------------------------|---|
| <b>VESA Mount (optional)</b> | <b>VESA Mount Screw</b>                             |
| x 1                          | x 4   |
| VESA Mount Kit               | M6x15mm screw (Round Head with spring washer screw) |
|                              | x 4   |
|                              | M4x10mm screw                                       |

## HDD Easy Maintenance




### HDD Accessories

#### HDD Tray Screw


- x 8  
M3x4.8mm Screw x 8

## Installing Hooks (optional)


**Step 1.** Install the mounting brackets into the mounting holes on the four sides of SP-S214 using 12 screws (M3x5mm).



**Step 2.** Mount SP-S214 Panel PC equipped with 12 brackets onto the wall firmly.




**Step 3.** Install 12 hooks onto the mounting brackets on the four sides of Panel PC and fasten the mating screws to secure firmly.



### Hook Accessories (optional)

- |                  |               |        |
|------------------|---------------|--------|
| x 12             | x 12          | x 12   |
| Mounting Bracket | M3x5mm screw  | M4 Nut |
|                  | x 12          | x 12   |
|                  | M4x35mm screw | Hook   |

## Installing Wall Oring (optional)



### Wall Oring Accessories (optional)

- |                     |             |
|---------------------|-------------|
| x 20                | x 20        |
| M3x 28mm screw x 20 | Washer x 20 |

# Safety Precaution

The following messages are reminders for safety on how to protect your panel PC from damages and extend the life cycle of SP-S214.

### 1. Check the Cable Voltage

- The range of operating voltage should be AC input ATX 250W. Otherwise, the panel PC could be damaged.

### 2. Environmental Conditions

- Place your SP-S214 on a sturdy, level surface. Be sure to allow enough space to have easy access around the device.
- Avoid extremely hot or cold place to install SP-S214.
- Avoid exposure to sunlight for a long period of time or in an airtight space.
- Avoid the device from any heating device or using SP-S214 when it's been left outdoors in a cold winter day.
- Avoid moving SP-S214 rapidly from a hot place to a cold place and vice versa because condensation may come from inside of the device.
- Don't place SP-S214 close to any radio-active device in case of signal interference.

### 3. Handling

- Avoid putting heavy objects on top of the device.
- If water or other liquid spills into this product, unplug the power cord immediately.

### 4. Good Care

- When the outside of the case is stained, remove the stain with a neutral washing agent with a dry cloth.
- Never use strong agents such as benzene and thinner to clean the device.
- If heavy stains are present, moisten a cloth with diluted neutral washing agent or with alcohol and then wipe thoroughly with a dry cloth.
- If dust has been accumulated on the outside, remove it by using a special vacuum cleaner for computers.
- The power cord with the plug shall be connected to a socket-outlet with earthing connections.

**CAUTION!** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

**WARNING!** Some internal parts of SP-S214 may have high electrical voltage. And therefore we strongly recommend that qualified engineers can open and disassemble the device. Please handle LCD and Touchscreen with extra care as they are easily breakable.